

NEW : BMW Z3 Clear Front Marker Lights

- 1) Purchase the clear front marker lights.



- 2) Disconnect the bulbs & the electrical motor from the headlights.
- 3) Disconnect the 7 metal clips on the headlights > indicated with the red lines
- 4) Dismantle the headlights > 4 bolts > indicated with yellow lines



- 5) Put the headlights into a 100° celcius preheated oven.
- 6) Remove the headlights after 10-15 minutes please beware for the heat
- 7) Than divide carefully the headlights in 2 with a large screwdriver
(don't worry it's that easy)



- 8) Remove the orange blinkers
- 9) Fix the new white blinkers with transparent silicone (*resisting to 150°c*) > indicated with the yellow lines.
- 10) Wait for about 5 hours than put the headlights again into a 100° celcius preheated oven.
- 11) Remove the headlights after 10-15 minutes & put them together (*beware for the heat*)



- 12) Assemble the headlights & adjust the lights again



- 13) Behold the new look of your Z3

